



## Fabric Soft Top Cleaner

### Do –

- Test on an inconspicuous area to ensure fabric is colourfast dyed.
- Spray mist the soft top with water prior to application.
- Use a clean paint brush to apply.
- Leave **Fabric Soft Top Cleaner** on for 10–20 minutes for general cleaning.
- Leave **Fabric Soft Top Cleaner** on for 40–60 minutes for stubborn dirt and to remove any previous waterproofing treatments.

- Wear protective gloves whilst applying.
- Use as often as required.

### Don't –

- Use a power jet wash to clean a fabric soft top.
- Use a detergent based cleaner.
- Apply in direct sunlight.
- Forget to shake the bottle prior to use.

## Ultra Proofer

### Do –

- Ensure that the soft top is thoroughly cleaned.
- Ensure that you have sufficient **Ultra Proofer** to complete a full coat.
- Keep a soft damp cloth ready to wipe off any splashes or dribbles on paintwork and glass.
- Work in a timely fashion to ensure that the edges of the freshly applied **Ultra Proofer** do not dry out too quickly.
- Work from the centre of the soft top and as quickly as possible progress towards each side, the front and the back of the soft top.
- Apply to a dry top and allow **Ultra Proofer** to dry completely before applying further product or taking out in the rain.
- Use every at least every 6–12 months.

### Don't –

- Use on vinyl soft tops.
- Forget to stir **not** shake the **Ultra Proofer** prior to use.
- Dilute or mix the **Ultra Proofer** with any other product.
- Apply the **Ultra Proofer** in direct sunlight, on a warm/hot soft top or a warm/hot day that will cause the **Ultra Proofer** to dry too quickly.
- Allow to dry on glass and paintwork.
- Apply to vinyl soft tops or cars with modified paintwork.
- Apply water proofing agent prior to using **Reviver**. Any proofer previously applied must be completely removed first.

## Soft Top Reviver

### Do –

- Ensure that the soft top is thoroughly cleaned.
- Ensure that you have sufficient **Reviver** to complete a full coat.
- Be diligent in removing previous waterproof coatings prior to application of **Reviver**.
- Keep a soft damp cloth ready to wipe off any splashes or dribbles on paintwork and glass.
- Work in a timely fashion to ensure that the edges of the freshly applied **Reviver** do not dry out too quickly.
- Work from the centre of the soft top and as quickly as possible progress towards each side, the front and the back of the soft top.
- Apply to a dry top and allow **Reviver** to dry completely before applying further product or taking out in the rain.

### Don't –

- Forget to shake the bottle or stir well prior to use.
- Dilute or mix the **Reviver** with any other product.
- Apply the **Reviver** in direct sunlight, on a warm/hot soft top or on a warm/hot day that will cause the **Reviver** to dry too quickly.
- Allow to dry on glass and paintwork.
- Apply to a soft top that has been coated with a waterproofing agent without removing the proofer first.
- Apply to vinyl soft tops or cars with modified paintwork.
- Apply to one half of the soft top first as this may achieve a join line when starting the second half of the soft top!

## Vinyl Soft Top Cleaner

### Do –

- Test on an inconspicuous area to ensure vinyl is colourfast dyed.
- Use a clean paint brush or sponge to apply.
- Leave **Vinyl Cleaner** on for 10–20 minutes for general cleaning.
- Leave **Vinyl Cleaner** on for 40–60 minutes for stubborn dirt.
- Wear protective gloves whilst applying.
- Allow to dry before applying **Vinyl Ultra Proofer**.
- Use as often as required.

### Don't –

- Use on fabric soft tops.
- Use a power jet wash to clean a vinyl soft top.
- Apply in direct sunlight.
- Forget to shake the bottle prior to use.

## Plastic Window Polish

### Do –

- Apply with a clean soft polishing cloth.
- Use small quantities of **Plastic Window Polish** working with circular motions in small areas a little at a time.
- Allow **Plastic Window Polish** to dry then with a clean soft cloth polish off using circular movements.
- Apply to both interior and exterior of window.

### Don't –

- Forget to shake the bottle thoroughly prior to use.

- Allow the **Plastic Window Polish** to come into contact with materials or the fabric that surrounds the window.

## Vinyl Ultra Proofer

### Do –

- Ensure that the soft top is thoroughly cleaned.
- Ensure that you have sufficient **Vinyl Ultra Proofer** to complete a full coat.
- Keep a soft damp cloth ready to wipe off any splashes or dribbles on paintwork and glass.
- Work in a timely fashion to ensure that the edges of the freshly applied **Vinyl Ultra Proofer** do not dry out too quickly.
- Work from the centre outwards round and round the vehicle.
- Apply to a dry top and allow **Vinyl Ultra Proofer** to dry completely before applying further product or taking out in the rain.
- Use at least every 3–6 months.

### Don't –

- Use on fabric soft tops.
- Forget to shake the **Vinyl Ultra Proofer** bottle prior to use.
- Dilute or mix the **Vinyl Ultra Proofer** with any other product.
- Apply the **Vinyl Ultra Proofer** in direct sunlight or on a hot day that will cause the **Vinyl Ultra Proofer** to dry too quickly.
- Allow to dry on glass and paintwork.
- Apply to fabric soft tops or cars with modified paintwork.